

miroir

Ultra Pro Projector

Quick Start Guide

© 2017 Miroir USA, LLC. All rights reserved. Miroir and the Miroir logo are owned by Miroir USA, LLC. All other trademarks are the property of their respective owners. Miroir USA, LLC assumes no responsibility for any errors that may appear in this manual. Information contained herein is subject to change without notice.

© 2017 Miroir USA, LLC. Tous droits réservés. Miroir et le logo Miroir sont la propriété de Miroir USA, LLC. Toutes les autres marques commerciales sont la propriété de leurs propriétaires respectifs. Miroir USA LLC décline toute responsabilité pour toute erreur pouvant apparaître dans cette notice d'utilisation. Les informations contenues dans les présentes peuvent être modifiées sans préavis.

© 2017 Miroir USA, LLC. Reservados todos los derechos. Miroir y el logotipo de Miroir son propiedad de Miroir USA, LLC. Todas las demás marcas comerciales son propiedad de sus respectivos propietarios. Miroir USA, LLC no asume ninguna responsabilidad por los errores que puedan aparecer en este manual. La información incluida aquí puede ser modificada sin previo aviso.

© 2017 Miroir USA, LLC. Todos os direitos reservados. Miroir e o logótipo Miroir são propriedade da Miroir USA, LLC. Todas as outras marcas comerciais são propriedade dos respetivos proprietários. Miroir USA, LLC não assume qualquer responsabilidade por quaisquer erros que possam surgir neste manual. A informação contida no presente documento está sujeita a alterações sem aviso.

© 2017 Miroir USA, LLC. Alle Rechte vorbehalten. Miroir und das Miroir-Logo sind Eigentum von Miroir USA, LLC. Alle anderen Warenzeichen sind das Eigentum ihrer jeweiligen Inhaber. Miroir USA, LLC haftet nicht für etwaige Fehler, die in dieser Bedienungsanleitung auftreten können. Die Informationen hierin können ohne Vorankündigung geändert werden.

© 2017 Miroir USA, LLC. Alle Rechte vorbehalten. Miroir und das Miroir-Logo sind Eigentum von Miroir USA, LLC. Alle anderen Warenzeichen sind das Eigentum ihrer jeweiligen Inhaber. Miroir USA, LLC haftet nicht für etwaige Fehler, die in dieser Bedienungsanleitung auftreten können. Die Informationen hierin können ohne Vorankündigung geändert werden.

© 2017 Miroir USA, LLC. Tutti i diritti riservati. Miroir e il logo Miroir sono proprietà di Miroir USA, LLC. Tutti gli altri marchi registrati appartengono ai rispettivi proprietari. Miroir USA, LLC declina ogni responsabilità per eventuali errori in questo manuale. Le informazioni contenute in questo manuale possono subire modifiche senza preavviso.


© 2017 Miroir USA, LLC สงวนลิขสิทธิ์ทั้งหมด Miroir และโลโก้ของ Miroir เป็นของ Miroir USA, LLC เครื่องหมายการค้าอื่นทั้งหมดเป็นทรัพย์สินของเจ้าของตามลำดับ Miroir USA, LLC ไม่รับผิดชอบต่อความผิดพลาดอันอาจปรากฏในคู่มือนี้ ข้อมูลซึ่งอยู่ในคู่มือนี้อาจเปลี่ยนแปลงได้โดยไม่ต้องแจ้งให้ทราบล่วงหน้า.

© 2017 Miroir USA, LLC. All rights reserved. MiroirおよびMiroirのロゴは、Miroir USA, LLCの所有物です。その他全ての商標は、各所有者の財産です。本マニュアルに誤りがある場合でも、Miroir USA, LLCはそれに対する責任を負いません。本書に記載されている情報は、通知なく変更される場合があります。

© 2017年美国Miroir公司版权所有。版权所有。Miroir品牌和Miroir 商标是属于美国Miroir公司。其他所有商标均归各商标拥有者所有。Miroir对本手册中可能出现的任何错误不承担任何责任。本手册中的信息可能会随时发生变动，恕不另行通知。

© 2017年美國Miroir公司版權所有。版權所有。Miroir品牌和Miroir 商標是屬於美國Miroir公司。其他所有商標均歸各商標擁有者所有。Miroir對本手冊中可能出現的任何錯誤不承擔任何責任。本手冊中的信息可能會隨時發生變動，恕不另行通知。


Your Miroir Ultra Pro Projector



- A Battery Indicator Lights** - Lights flash in turn as the device charges. The battery is fully charged when all the lights illuminate and no longer flash.
- B Lens Cover/Power** - Slide lense cover to turn device on. Battery charging lights will flash in turn during projector power on
- C Projection Lens**
- D Audio Out (3.5mm)** - (Optional) Connect an external speaker or headphones.
- E HDMI Video Input** - Connect an HDMI cable to a device that supports HDMI video output.
- F USB Power Output** - Connect a USB power cable to provide power to a HDMI streaming stick or to charge a smartphone battery. Cannot be used for video input.
- G USB-C Charge/Video Input** - Connect the supplied USB-C Charge/Video cable to a device that supports USB-C video output, or connect the supplied USB-C Charge/Video cable to your MacBook Pro AC Adapter to charge the projector's internal battery. Note: Projector battery will not charge and project simultaneously via a USB-C connection. Fully charge the battery before first use (approximately 4-5 hours).
- H Reset Button** - Press to reset projector.
- I DC Power Input**
- J Source Input Button** - Press to change input source.
- K Focus Mode** - Press button then use volume +/- buttons to adjust.
- L Volume Controls** - Increase/decrease the volume output of the projector. Press Volume - button to see battery level remaining.Z
- M Rubber Foot Pads** - Provides stability and proper airflow to cooling vents.
- N Cooling Vent**
- O Tripod Mount** - Will fit a standard sized tripod screw. Tripod not included.

Included in the Box:

- USB-C Charge/Video Cable
- HDMI Cable
- Micro HDMI Adapter
- Quick Start Guide
- Remote
- AC Adapter/Charger
- Projector Drawstring Pouch




Your Miroir Ultra Pro Projector Remote Control

- | | |
|---------------------------|-----------------------------------|
| A Power | E USB-C Video Input Select |
| B Invert Image | F Volume Control |
| C Eco Power On/Off | G HDMI 1 Input Select |
| D Motorized Focus | H HDMI 2 Input Select |


Connect Your Device Using HDMI

To connect your Apple device to a Miroir projector, you will need an Apple Digital AV Adapter (sold separately) and an HDMI cable (included in the box).



Connect Your MacBook Pro and MacBook Using USB-C

To connect your Macbook to a Miroir projector, you will need a USB-C Video Cable (included in the box).



IMPORTANT! Not all USB - C cables will support video. The USB-C cable that comes with the projector will support video and charging.

Troubleshooting

The image is not square

- Check that the projector's lens is parallel to your projection surface and that your projection surface is flat.

No sound

- Check the volume control on your source device to ensure the volume is turned up.
- Check the volume control on the projector to ensure the volume is turned up.
- If you are using an adapter, verify that the adapter supports audio.
- Check that the HDMI cable is fully plugged into the HDMI port.

No Signal Message

- Check that you are using the required cable and/or adapter.
- If you are using a digital AV adapter, check that the adapter is an authentic Apple adapter and is compatible with your model phone or tablet.
- If you are connecting via USB-C, check that you are using the USB-C video cable that came with the projector – this cable is labeled “USB-C Video Connector.” Some USB-C cables do not support video.
- If you are connected to a laptop or computer, check your computer display settings to ensure a multiple display option is selected (such as “duplicate these displays”).
- Check that your source device supports HDMI video out or USB-C video out.

Projector will not power on, or stay powered on

- Check the battery life of the projector. If one or fewer lights are illuminated, charge the battery with the USB – C cable and your MacBook USB – C power adapter, or the AC Power Adapter included with the projector.

The image is blurry

- Press the motorized focus buttons on the remote, or side of the projector to focus the image.
- Check that the surface you are projecting on is smooth and non-reflective.

Learn More

To learn more about your Miroir HD Pro Projector and its operations, to review specs, and find answers to frequently asked questions, please visit:

www.miroirusa.com

miroir

www.miroirusa.com